

Engine Compartment Wiring Color Codes



Category: [Tech](#) | Published: Saturday, 28 June 2014 22:33 | Written by Administrator | Hits: 3889

ENGINE BAY COLORS		1958 MG-ZB Magnette			
Voltage Regulator		Heater Motor		Horns	
A1	36= BRN / BLU	o	23= GR / BRN (to switch)	o	35= BRN / YL (BOTH)
A1	37= BRN / WHT	o	57= BLK (GROUND)	o	57= BLK (BOTH)
F	29= YL / GR				
D	25(2)= YL	Wiper Motor		Fog lights	
E	57= BLK	o	62= BLK / GR	RH	51= PUR / YL
		o	57= BLK (GROUND)	o	57= BLK
Reverse Lamp Switch					
o	17= GR	Horn Relay		LH	56= PUR / BLK
o	23= GR / BRN	C1	35(2)= BRN / YL	o	57= BLK
		C2	38= BRN / GR		
		W	40= BRN / BLK		
Coil					
o	16= WHT / BLK (to Dist.)	Starter Solinoid		Running / Turn Lights	
O	Dist. Wire	o	To Starter	RR	41= RED
o	9= WHT (to Fuse)	O	10= WHT / RED	TR	21= GR / WHT
		o	To Batt. & 33= BRN	o	57= BLK
Stop Lamp Switch					
o	22= GR / PUR	Fuse Box		RL	41= RED
o	17= GR	A1	33(2)= BRN	TL	18= GR / RED
		A2	38(3)= BRN / GR	o	57= BLK
Directional Indicator Flasher		A3	9(2)= WHT		
L	23= GR / BRN	A4	17(2)= GR		
B	17= GR	A4	17(2)= GR		
P	66= Lite GR				
		Generator		Water Temp Sensor	
Directional Indicator Relay Unit		D	25= YL	o	20= GR/BLU
1	23= GR /BRN	F	29= YL / GR		
2	18= GR / RED				
3	14= WHT / PUR				
4	20= GR / BLU			HeadLights	
5	22= GR / PUR			RD	2= BLU / RED
6	21= GR / WHT			RB	4= BLU / WHT
7	15= WHT / BRN			o	57= BLK
8	19= GR / YL				
				LD	2= BLU / RED
				LB	4= BLU / WHT
				o	57= BLK
***	Voltage Reg with Alt.	***	Alternator (option)		
A1	Splice "A" & "A1"				
A1		F	at reg, spice to YL to dash		
F	Splice to "D, YL" to Dash	O	to Batt side at Starter Sol		
D		O	" " " " " " " " " "		
D	YL to Alt is Blank	only the "E" is Conn. on Reg.			
E	57= BLK				
only the "E" is Conn. on Reg.					